## **Breveté Iron Safe**





## To Open

- I. Move mechanized boss up and right.
- 2. Insert small key rotate clockwise one quarter turn to expose remaining two keyholes.



3. Rotate small key counter clockwise ½ turn from starting position, push into second stage of lock and rotate one full turn counter clockwise.

4. Insert large key in center and medium key in left keyholes.



- 5. Rotate large key quarter turn counter-clockwise and push in to stopping point.
- 6. Rotate medium key counter-clockwise eighth turn and hold spring while rotating large key clockwise one full turn.
- 7. Release medium key and rotate clockwise half turn against latch spring and hold while opening.



(shown with deadbolts engaged)

## To Lock

- 1. Rotate medium key half turn clockwise to retract latch while closing.
- 2. Release medium key.
- 3. Rotate small key one full turn clockwise.
- 4. Rotate large key counter-clockwise to engage deadbolts.
- 5. Remove all keys.
- 6. Close keyhole covers by hand.

